

MOTORIZED



If you are experiencing any difficulties with this product,
DO NOT RETURN THE PRODUCT DIRECTLY TO THE STORE,
Please contact Hunter Products Customer Service at
www.electricrideon.com.au
or **Toll Free Number 1800 224 094** for service assistance.



6V BMW i8 Spyder Owner's Manual and Assembly Instructions

Model 5620

Read and understand the entire manual before assembly and operation. The vehicle must be assembled by an adult who has read and understands the instructions.

Made in China.

Styles and colors may vary.

Save this manual with your sales receipt.



BMW i8 Children's Electronic Car manufactured by Paragon Child Products Co., Ltd. The BMW trademarks are used under license from BMW AG. BMW i8 name and associated logos are trademarks of BMW AG.

Introduction

Thank you for purchasing the BMW i8. We hope the rider enjoys it for miles to come. Please read this instruction guide carefully before assembling and operating the vehicle.

Please contact Customer Service with any questions.

Web: www.electricrideon.com.au

Phone: 1800224094

Specifications:

BATTERY	6V 7AH
MOTOR	6V 20W
AGE	3 Years and Up
MAX WEIGHT	77 lbs.
PRODUCT SIZE	25.2 in. x 15.75 in. x 50 in.
SPEED	2.0 MPH
RECHARGE TIME	8-12 Hours
TYPICAL RUN TIME	1-2 Hours
CHARGER OUTPUT	DC 7.0V0.8A

IMPORTANT!

**YOU MUST CHARGE THE BATTERY
FOR 24 HOURS BEFORE FIRST USE!**

Charge the battery after each use.

Charge the battery at least once a month, even if the vehicle is not in use.

DO NOT RETURN THIS ITEM
TO THE STORE!

Contact Customer Service if you need assistance or replacement parts.

www.electricrideon.com.au
1800224094

**Read this entire manual to ensure
proper assembly and safe operation
of the vehicle.**



Safety	6
Parts	8
Charging Instructions	9
Assemble the Front Wheels	10
Assemble the Left Rear Wheel	11
Assemble the Right Rear Wheel	12
Attach the Steering Wheel	13
Attach the Mirrors	14
Attach the Seat	15
Battery Removal	16
Operating Instructions	17
Maintenance	18
General Care	19
Troubleshooting Guide	20
Service and Repairs	22
Warranty	23

6 Safety



WARNING: SAFETY RIDING RULES

PREVENT INJURIES AND DEATHS:

- NEVER LEAVE CHILD UNATTENDED. ALWAYS keep child in view when child is in vehicle. Direct adult supervision is REQUIRED.
- NEVER use on roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water.
- ALWAYS wear shoes.
- ALWAYS sit on the seat.
- NEVER allow more than (1) rider in the vehicle.
- Risk of fire. Do not bypass.

The user must follow all safety rules and guidelines, or serious injury or death may occur to the user.

Always use common sense and safe practices when using the vehicle. The user must be at least 3 years old and weigh no more than 77 lbs.

This product contains small parts that are for adult assembly only.

Keep small children away when assembling. Remove and dispose of all protective material and plastic bags before assembly.

Riding the vehicle without a helmet. Riders must always wear a fitted helmet that complies with Australian Standard

AS/NZS 2063:2008.

Do not overload the vehicle. Do not remove the weight restriction decals.

Do not pull the vehicle with another vehicle or similar device.

Keep body parts such as hands, legs, hair and clothing away from moving parts. Moving parts can cause serious injury.

Do not operate near loose dirt, mud, sand or fine gravel.

Do not operate near flammable vapors (gasoline, paint thinner, acetone, etc.).

Always use the vehicle in a safe, secure environment with adult supervision.




WARNING: BATTERY SAFETY

- Battery posts, terminals and related accessories contain lead and lead compound (acid) chemicals known to the state of California to cause cancer, reproductive harm, and are toxic and corrosive. DO NOT open the battery.



- Contact exposure to battery leakage (lead acid) may cause serious injury. Immediately contact your doctor if exposure occurs. If the chemical is on the skin, flush immediately with cool water for 15 minutes. If the chemical is swallowed, immediately give the person water or milk. Do not give water or milk if the person is vomiting or has decreased alertness. Do not induce vomiting.



- Tampering with or modifying the electric circuit system may cause shock, fire or explosion. It could permanently damage the system. Keep the charger housing closed to prevent exposed wiring, which may cause electric shock.


IMPORTANT: Before using the vehicle for the first time, the battery must be charged for a full 24 hours (no more than 30 hours).



WARNING: ADULT SUPERVISION REQUIRED

- Before using the vehicle, the rider must understand the vehicle controls and safety issues.
- It is the responsibility of the adult to educate the child and to determine if the child is capable of understanding the vehicle controls.
- An adult must ALWAYS directly supervise the use of this vehicle.
- NEVER leave a child unsupervised in the vehicle.

8 Parts



- | | |
|----------------------------|----------------------------|
| 1. Windshield | 12. Rims (4) |
| 2. Mirrors (2) | 13. Snap Pins (4) |
| 3. Steering Wheel Assembly | 14. Rear Thick Washer |
| 4. Seat | 15. Thin Washers (4) |
| 5. Spoiler | 16. Front Thick Washer (2) |
| 6. Right Door | 17. Hubcaps (4) |
| 7. Left Door | 18. Charger |
| 8. Rear Caps (2) | 19. Battery |
| 9. Rear Wheels (2) | 20. Front Grill |
| 10. Front Wheels (2) | 21. Front Panels (2) |
| 11. Inner Wheel Spacer | 22. Dashboard |

Not Included:



- Phillips screwdriver
- Pliers

YOU MUST CHARGE THE BATTERY FOR 24 HOURS BEFORE THE FIRST USE!

ONLY AN ADULT SHOULD HANDLE THE BATTERY AND CHARGER.


To Charge the Battery:

1. Ensure the car is stopped and turned off.
2. Unlock and remove the seat.
3. Unplug the red battery connector (A) from the red engine connector (B).
4. Connect the red battery connector (A) to the red battery charger connector (C) and plug (D) into a 120 V outlet.




To Unplug the Battery:

1. Unplug the battery charger (D) from the outlet.
2. Unplug the red battery connector (A).
3. Reconnect the red battery connector (A) to the red engine connector (B).
4. Replace the seat and tighten lock.




Note: It is not necessary to remove the battery for charging. However, if the battery does not reach the outlet, it can be removed for charging. For Battery Removal instructions, see Page 16.

10 Assemble the Front Wheels




1. Slide the front thick washer (16) onto the axle
2. Slide the front wheel (10) onto the front wheel axle
3. Slide the thin washer (15) onto the axle
4. Push the straight end of the snap pin (13) into the hole on the front wheel axle to secure the parts into place
5. Snap the rim onto the wheel (12), and snap the hubcap (17) onto the rim
6. Repeat steps 1-5 for the other front wheel




1. Slide the thick rear washer (14) onto the rear wheel axle
2. Slide the inner wheel spacer onto the rear left wheel axle
3. Slide the rear wheel onto the axle
4. Slide the thin washer onto the rear axle
5. Push the straight end of the snap pin (13) into the hole on the axle
6. Snap the rim onto the wheel, and snap the hubcap onto the rim

12 Assemble the Right Rear Wheel




1. Slide the rear wheel with the gear teeth facing inward onto the right rear wheel axle
2. Line up the gear teeth on the wheel with the grooves on the gear box
3. Slide the thin washer onto the rear wheel axle
4. Push the straight end of the snap pin through the hole on the rear wheel axle
5. Snap the rim onto the wheel, and snap the hubcap onto the rim

Attach the Steering Wheel 13




1. Remove the screw and nut from the steering wheel assembly (3) before attaching.
2. Plug the steering wheel connector (A) into the dashboard connector (B). Please pay attention not to hurt the wire when you are installing, and not to flap the steering wheel clavier.
3. Insert the steering wheel (3) into the steering rod, and match the screw holes of the steering wheel and the steering rod.
4. Insert the screw into the hole and fasten the nut to secure.

14 Attach the Mirrors




1. Insert the left mirror into the slot on the left door near the windshield
2. Push down on the mirror until it clocks into place
3. Repeat steps 1-2 for the right mirror

Attach the Seat 15



1. Position the seat over the battery compartment
2. Slide in the latches on the back of the seat into the slots on the body of the car
3. Turn the thumbscrew on the seat clockwise to lock it into place


16 Battery Removal



1. Disconnect the red battery connector (A) from the red engine connector (B) .
2. Loosen and remove the screw.
3. Pull out the battery strap bar.
4. Remove the battery.

Note: It is not necessary to remove the battery for charging. However, if the battery does not reach the outlet, it can be removed for charging.

Operating Instructions 17



- **Power Switch:** Press the power switch to turn on the car. A power light will indicate that the car is turned on. Press the power switch to turn off the car.
- **Dashboard Lights:** The dashboard lights will light up when the power switch is pushed to on.
- **Gas Pedal:** Press the gas pedal to put the car in motion. Release to stop. The headlights will turn on when the car is moving forward.
- **Shifter:** Push the up to move forward, press down to move in reverse.

18 Maintenance

Important Battery and Charger Information

- Only an adult who has read and understands the safety warnings may handle and operate the battery and battery charger. Keep away from children.
- Charge the battery for 24 hours before using the vehicle for the first time.
- Charge the battery immediately after each use. Charge for at least 8-12 hours, but no more than 20 hours.
- Charge the battery at least once a month, even if the vehicle is not used or stored.
- Never leave the battery in a discharged condition.
- Connect the terminal of the battery and charger, then plug the charger into a 120V AC outlet.
- It is normal for the charger to heat slightly. If the charger rises above 71°C / 160°F, disconnect the charger and call Customer Service for assistance.
- Keep the charger away from water or excessive moisture to prevent short-circuiting.
- Only use the charger specified with the original item. **Do not charge the battery with any other charger.**
- Do not attempt to recharge non-rechargeable batteries with the original charger.
- **Do not replace the battery with any other battery, or the warranty will be voided.** If you need a replacement battery, see Page 24 for replacement information.
- Remove damaged batteries from the car immediately. Recycle or dispose of the used batteries responsibly.
- Do not short circuit the supply terminals.
- Do not leave the battery connected in the vehicle for extended periods of time when the vehicle is not being used. Disconnect the battery connector from the engine connector before storing.
- The vehicle is equipped with a thermal fuse to protect the electric circuit. If the vehicle cuts out, turn the vehicle off and on to reset.

- Regularly inspect all vehicle parts to ensure they are in good working condition.
- Regularly inspect the charger, cord, plug, and other related parts for damage.
- Remove any damaged parts and immediately contact Customer Service for replacement parts. See Service and Repairs on Page 24 for more information.
- DO NOT operate the vehicle if there are any damaged parts.
- Carefully clean the vehicle with a damp cloth and mild soap. Do not get water in or near any electrical parts. Do not wash the vehicle with a hose.
- Store the vehicle indoors or use a tarp to cover it. Keep away from stoves, heaters, or other sources of heat.

20 Troubleshooting Guide

Completely read through the manual and troubleshooting guide before contacting Customer Service at www.electricrideon.com.au or call 1800224094 .

Problem	Potential Cause	Solution
Vehicle does not run	Battery is low	Recharge the battery
	Thermal fuse tripped	Reset fuse
	Snap pins are loose	Tighten snap pins
	Loose wires or loose connectors	Ensure the battery connectors are securely attached. If wires are loose, contact Consumer Service for repairs
	Battery is dead	Contact Customer Service for replacement battery
	Electrical system is damaged	Contact Customer Service for repairs
	Motor is damaged	Contact Customer Service for repairs
Vehicle only runs for a short time	Undercharged battery	Ensure a secure connection when the battery is recharging. Recharge for at least 8-12 hours
	Overcharged battery	Never charge the battery for more than 30 hours
	Battery is old	Replace battery
Vehicle runs slowly	Battery is not fully charged	Ensure a secure connection when the battery is recharging
	Battery is old	Contact Customer Service to order replacement battery
	Too much weight on vehicle	Reduce weight on vehicle (77 lbs max)
	Harsh conditions	Operate the vehicle on level ground and safe surfaces

Problem	Potential Cause	Solution
Vehicle needs a push to start	Loose wires or loose connectors	Ensure the battery connectors are securely attached. If wires are loose, contact Consumer Service for repairs
	"Dead spot" on motor	A "dead spot" means electricity is not being delivered to the terminal. Contact Consumer Service for repairs
Difficulty shifting	Attempting to shift while vehicle is moving	Stop the vehicle before shifting
Motor or gear box making grinding noises	Motor or gear damage	Contact Consumer Service for repairs
Battery will not recharge	Charger is not plugged in	Plug in the charger to a functional wall outlet
	Charger is not working	Contact Consumer Service for a replacement
	Loose connector or loose adapter	Check that the connectors are securely plugged in to each other
Battery makes bubbling noise while recharging	This is normal	No action required
Charger is warm	This is normal	No action required

Do not return this vehicle to the store.

If your product requires service, repairs or replacement parts, please visit us online at www.electricrideon.com.au or call 1800224094 v

One-Year Limited Warranty

Hunter Products warrants that your BMW i8 6v will be free from defects in materials and workmanship for the vehicle (except for the 6-volt battery) for a period of 12 months, from the date of purchase. This warranty only applies where the product is completely and correctly assembled and used in accordance with all accompanying recommendations and users instructions. This warranty is in addition to your rights under the Australia Consumer Law.

Hunter Products, at its option will provide you with a refund or replacement parts for this product if the BMW i8 6v becomes defective within the warranty period. Hunter Products will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of an accident, misuse, abuse, neglect or other causes not arising out of defects in materials or workmanship, nor does it cover damages arising out of damages arising out of service by other than an authorised service person.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Please retain your receipt as proof of purchase and contact Hunter Products for further assistance on how to process any warranty claims.

Business name: Hunter Products Pty Ltd
Business address: Level 2, 424 Warrigal Road, Moorabbin VIC 3189, Australia
Telephone number: Australia wide (local call cost) 1800224094
(Monday to Friday 8.30 to 4.30pm AEST)
Email address: www.electricrideon.com.au

